HYDROGEN SAFETY CHECKLIST

It is a common application of hydrogen technologies to have an outdoor hydrogen supply system providing for an indoor use. The Hydrogen Safety Panel developed a checklist to help both new and experienced hydrogen users identify considerations necessary to ensure a safe installation. The checklist is not intended to replace or provide guidance on compliance. Rather, it presents a concise table of critical safety measures compiled by some of the hydrogen industry's foremost safety experts. Figure B.1 illustrates the system considered by the Panel in developing the checklist. The general principles in the checklist apply to all types and sizes of hydrogen systems.




Figure B.1. Outdoor hydrogen supply system for indoor use

Hydrogen safety, much like all flammable gas safety, relies on five key considerations:

- 1. Recognize hazards and define mitigation measures (plan).
- 2. Ensure system integrity (keep the hydrogen in the system).
- 3. Provide proper ventilation to prevent accumulation (manage discharges).
- 4. Ensure that leaks are detected and isolated (detect and mitigate).
- 5. Train personnel and ensure that hazards and mitigations are understood and that established work instructions are followed (manage operations).

The checklist is organized using these key considerations. Examples are included to help users identify specific prevention techniques.

The checklist is intended to assist people developing designs for hydrogen systems as well as those involved with the risk assessment of hydrogen systems. While these considerations are fairly inclusive, it is not possible to include all variables that need to be considered. The hazard analysis process should therefore include personnel who are familiar with applicable codes and standards in addition to team members with expertise in the technical aspects of the specific project.

Useful References:

Hydrogen Incident Reporting and Lessons Learned Database: http://www.h2incidents.org

Hydrogen Safety Best Practices: http://h2bestpractices.org/default.asp

NFPA 2, "Hydrogen Technologies Code": http://www.nfpa.org

NFPA 52, "Vehicular Gaseous Fuel Systems Code": http://www.nfpa.org

DOE Hydrogen Safety Program: http://www.hydrogen.energy.gov/safety.html

Hydrogen Safety Checklist Framples of Actions

	Approach	Examples of Actions
		☐ Identify risks such as flammability, toxicity, asphyxiates, reactive materials, etc.
		\square Identify potential hazards from adjacent facilities and nearby activities
		Address common failures of components such as fitting leaks, valve failure
		positions (open, closed, or last), valves leakage (through seat or external), instrumentation drifts or failures, control hardware and software failures, and
	Recognize hazards and	power outages.
	define mitigation	☐ Consider uncommon failures such as a check valve that does not check, relief
	measures	valve stuck open, block valve stuck open or closed, and piping or equipment
rk		rupture.
٧o		☐ Consider excess flow valves/chokes to size of hydrogen leaks
e V		☐ Define countermeasures to protect people and property.
Plan the Work		\square Follow applicable codes and standards.
an	Isolate hazards	☐ Store hydrogen outdoors as the preferred approach; store only small quantities
Ы		indoors in well ventilated areas.
		☐ Provide horizontal separation to prevent spreading hazards to/from other
		systems (especially safety systems that may be disabled), structures, and combustible materials.
		☐ Avoid hazards caused be overhead trees, piping, power and control wiring, etc.
		Provide adequate access for activities including:
	Provide adequate access	☐ Operation, including deliveries
	and lighting	☐ Maintenance
		☐ Emergency exit and response
	Approach	Evamples of Actions
	Appidacii	Examples of Actions
	Αρμισασιι	Determine maximum credible pressure considering abnormal operation,
	Арргоасп	☐ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve
	Арріодсіі	Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure.
u		 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are
tem	Design systems to	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with
ystem	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service.
e System	Design systems to	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with
the System	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after
교.	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer
교.	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections.
교.	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide
교.	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst.
교.	Design systems to withstand worst-case conditions	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst. □ Mount vessels and bottled gas cylinders securely.
교.	Design systems to withstand worst-case	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst.
교.	Design systems to withstand worst-case conditions	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst. □ Mount vessels and bottled gas cylinders securely. □ Consider that systems must operate and be maintained in severe weather and
교.	Design systems to withstand worst-case conditions	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst. □ Mount vessels and bottled gas cylinders securely. □ Consider that systems must operate and be maintained in severe weather and may experience earthquakes and flood water exposures.
_	Design systems to withstand worst-case conditions	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst. □ Mount vessels and bottled gas cylinders securely. □ Consider that systems must operate and be maintained in severe weather and may experience earthquakes and flood water exposures. □ De-mobilize vehicles and carts before delivery transfers or operation.
교.	Design systems to withstand worst-case conditions	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst. □ Mount vessels and bottled gas cylinders securely. □ Consider that systems must operate and be maintained in severe weather and may experience earthquakes and flood water exposures. □ De-mobilize vehicles and carts before delivery transfers or operation. □ Protect against vehicle or accidental impact and vandalism. □ Post warning signs. □ Avoid excess number of deliveries/change-outs if too small.
교.	Design systems to withstand worst-case conditions Protect systems	 □ Determine maximum credible pressure considering abnormal operation, mistakes made by operators, etc., then design the system to contain or relieve the pressure. □ Contain: Design or select equipment, piping and instrumentation that are capable of maximum credible pressure using materials compatible with hydrogen service. □ Relieve: Provide relief devices that safely vent the hydrogen to prevent damaging overpressure conditions. □ Perform system pressure tests to verify integrity after initial construction, after maintenance, after bottle replacements, and before deliveries through transfer connections. □ Design systems to safely contain maximum expected pressure or provide pressure relief devices to protect against burst. □ Mount vessels and bottled gas cylinders securely. □ Consider that systems must operate and be maintained in severe weather and may experience earthquakes and flood water exposures. □ De-mobilize vehicles and carts before delivery transfers or operation. □ Protect against vehicle or accidental impact and vandalism. □ Post warning signs.

	Provide hydrogen	☐ Locate automatic fail-closed shutoff valves at critical points in the system (such as storage exit, entry to buildings, inlets to test cells, etc.) to put the system in a safe state when a failure occurs.
	shutoff(s) for isolation	☐ Consider redundant or backup controls.
		☐ Install manual valves for maintenance and emergencies.
	Prevent cross-	\square Prevent back-flow to other gas systems with check valves, pressure differential,
	contamination	etc.
	Approach	Examples of Actions
les l	Safely discharge all process exhausts, relief	 □ Discharge hydrogen outdoors or into a laboratory ventilation system that assures proper dilution. □ Direct discharges away from personnel and other hazards.
J.B	valves, purges, and vents	☐ Secure/restrain discharge piping.
Manage Discharges	Prevent build-up of combustible mixtures in enclosed spaces	 □ Do not locate equipment or piping joints/fittings in poorly ventilated rooms or enclosed spaces. Use only solid or welded tubing or piping in such areas. □ Provide sufficient ventilation and/or space for dilution. □ Avoid build-up of hydrogen under ceilings/roofs and other partly enclosed spaces.
۱a	Remove potential ignition	☐ Proper bonding and grounding of equipment.
=	sources from flammable	□ No open flames.
	spaces/zones	☐ No arcing/sparking devices, e.g., properly classified electrical equipment.
	Approach	Examples of Actions
		☐ Provide detection and automatic shutdown/isolation if flammable mixtures
ate	Leak detection and mitigation	present, particularly in enclosed spaces. ☐ Consider methods for manual or automatic in-process leak detection such as ability for isolated systems to hold pressure.
tig		Periodically check for leaks in the operating system.
Ξ	Loss of forced ventilation indoors	Automatically shut off supply of hydrogen when ventilation is not working.
au		☐ Provide alarms for actions required by people, e.g., evacuation.
; a	Monitor the process and	☐ Provide capability to automatically detect and mitigate safety-critical situations.
l さ	Monitor the process and	
Detect and Mitigate	Monitor the process and protect against faults	 □ Consider redundancy to detect and mitigate sensor or process control faults. □ Provide ability for the system to advance to a "safe state" if power failures or controller faults are experiences.
Detect	_	☐ Provide ability for the system to advance to a "safe state" if power failures or
Detect	protect against faults Fire detection and	 □ Provide ability for the system to advance to a "safe state" if power failures or controller faults are experiences. □ Appropriate fire protection (extinguishers, sprinklers, etc.).
	protect against faults Fire detection and mitigation Approach	 □ Provide ability for the system to advance to a "safe state" if power failures or controller faults are experiences. □ Appropriate fire protection (extinguishers, sprinklers, etc.). □ Automatic shutdown and isolation if fire detected. ■ Examples of Actions □ Responsibilities for each of the parties involved. □ Operating procedures. □ Emergency procedures.
Operations	protect against faults Fire detection and mitigation	 □ Provide ability for the system to advance to a "safe state" if power failures or controller faults are experiences. □ Appropriate fire protection (extinguishers, sprinklers, etc.). □ Automatic shutdown and isolation if fire detected. ■ Examples of Actions □ Responsibilities for each of the parties involved. □ Operating procedures. □ Emergency procedures. □ Preventive maintenance schedules for equipment services, sensor calibrations, leak checks, etc. □ Safe work practices such as lock-out/tag-out, hot work permits, and hydrogen line purging.
Operations	Fire detection and mitigation Approach Establish and document	 □ Provide ability for the system to advance to a "safe state" if power failures or controller faults are experiences. □ Appropriate fire protection (extinguishers, sprinklers, etc.). □ Automatic shutdown and isolation if fire detected. ■ Examples of Actions □ Responsibilities for each of the parties involved. □ Operating procedures. □ Emergency procedures. □ Preventive maintenance schedules for equipment services, sensor calibrations, leak checks, etc. □ Safe work practices such as lock-out/tag-out, hot work permits, and hydrogen
	Fire detection and mitigation Approach Establish and document	 □ Provide ability for the system to advance to a "safe state" if power failures or controller faults are experiences. □ Appropriate fire protection (extinguishers, sprinklers, etc.). □ Automatic shutdown and isolation if fire detected. ■ Examples of Actions □ Responsibilities for each of the parties involved. □ Operating procedures. □ Emergency procedures. □ Preventive maintenance schedules for equipment services, sensor calibrations, leak checks, etc. □ Safe work practices such as lock-out/tag-out, hot work permits, and hydrogen line purging.